

AP800364 Mousse kitchen scale

Instruction Manual

Important Advice

1. Please read the instructions carefully before using the scale.
2. Ensure that there is nothing on the weighing plate when the scale is not being used.
3. Don't allow water (or any other liquid) to come into the scale.
4. When using the scale always place it on a solid, smooth and horizontal surface.
5. For best accuracy, place the scale at a safe distance of at least 1.5 meters from the operating microwave oven or it must be switch off.

Controls

1. Button: ON/ TARE/OFF

“ON” --- Press this button to switch on when the scale is turned off.

“OFF” --- Press this button for three seconds to switch off.

“TARE” --- Press this button to set back the display to “0”.

2. Button: g/oz,

--- Please find this button at the backside of the scale.

--- Press this button to change the units displayed from grams (g) to ounces (oz) or ounces (oz) to grams (g).

Battery

The scale works on 2pcs AAA batteries.

1. Insert the battery into the battery compartment, making sure that the polarities are correct, and, if such protection is provided, pull the plastic transparent protection from under the battery to initialize the battery.
2. Replace battery as soon as “Lo” is displayed and ensure that it is disposed of at an officially assigned place, for it may pollute the environment.

Operation

1. Press button “ON/ TARE/OFF” to switch on and “0g” or “0.00 oz” is displayed.
2. Place the ingredient(s) to be weighed directly on the weighing plate, you can read the weight right away. Note: please put the ingredient(s) in the middle of the

weighing plate, the precision will be depressed if putting the ingredient(s) on the corner.

3. Press button “ON/ TARE/OFF” for three seconds to switch off when “0” is in the display. Automatically power off when the scales have not been used for 60 seconds.
4. Capacity: 5Kg and Graduation: 1g
5. Overloading display: “EEEE” becomes visible in the display if the weighing plate has been overburdened.

◊ Adding ingredients

1. Each time you press the “ON/ TARE/OFF” button, the weight on the display is set back to “0” again, irrespective of the ingredient(s) that are already on weighing plate. For example:

Switch on → Display “0” → Place the ingredient(s) to be weighed → Display the weight → Press the button “ON/ TARE/OFF” → Set back to “0” → Place the adding ingredient(s) → Display the weight of the adding ingredient(s) → Press the button “ON/ TARE/OFF” → set back to “0” again →...

Cleaning and Storage

1. Clean the scale with a soft slightly damp cloth and if necessary, some detergent. Never use hot water or other harsh chemicals to clean the scale.
2. Ensure that there is nothing on the weighing plate when the scale is not being used.
3. The scale should not be stored standing on its side.
4. Never attempt to open the scale and tamper with its mechanism or circuitry.
5. Remove the battery if the scale is not going to be used for a long time.

This item is in conformity with the following standards:

RoHS Directive 2011/65/EU and its subsequent amendments Directive (EU) 2015/863

Electromagnetic Compatibility (EMC) - Directive 2014/30/EU



This symbol on the product packaging and user manual indicates that the device should be disposed of separately from household waste at the end of its service life. This sign ensures that the raw material is properly recycled. Contact your local authority for more information.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.



Distributor: Cool Collection, 1476 Budapest, POB:176. Hungary

Registration nr.: 01-09-276783

Made in China

AP800364 Mousse konyhai mérleg

Használati utasítás

Fontos tanácsok:

1. Kérem figyelmesen olvassa el az utasításokat mielőtt használja a mérleget.
2. Használat előtt győződjön meg róla, hogy nincs semmi a mérleg felületén.
3. Ne engedjen vizet (vagy más folyadékot) a mérlegbe.
4. Használatkor mindenkor szilárd, sima, vízszintes felületre helyezze a mérleget.
5. A legnagyobb pontosság érdekében helyezze a mérleget legalább 1,5 méteres távolságba a működő mikrohullámú sütőtől vagy kapcsolja ki azt.

Beállítások

1. ON/ TARE/OFF gombok

“ON” Bekapcsoláshoz nyomja meg ezt a gombot, ha a mérleg ki van kapcsolva.

“OFF” Nyomja 3 másodpercig ezt a gombot a kikapcsoláshoz.

“TARE” Nyomja ezt a gombot, ha a kijelzőt vissza akarja állítani “0” állásba.

2. g/oz gomb

--- Ezt a gombot a mérleg hátoldalán találja.

--- Nyomja meg ezt a gombot, ha a mértékegységet grammiból (g) unciába (oz) vagy unciából (oz) grammiba (g) akarja átállítani.

Elemek

A mérleg 2 db AAA elemmel működik.

1. Tegye az elemeket az elemtártó rekeszbe, ügyeljen a helyes polaritásra, és ha ezeket az óvintézkedéseket megtette, húzza ki a műanyag átlátszó szigetelést az elemek közül, hogy azok alaphelyzetbe kerüljenek.
2. Cserélje ki az elemeket, ha a kijelzőn a “Lo” felirat jelenik meg és a használt elemeket az erre hivatalosan kijelölt helyre dobja ki, mert környezetszennyezők.

Működés

1. A bekapcsoláshoz nyomja meg az “ON/ TARE/OFF” gombot és a kijelzőn “0g” vagy “0.00 oz” jelenik meg.
2. Helyezze a megmérni kívánt terméke(ke)t közvetlenül a mérő felületre és

azonnal leolvashatja a súlyát. Fontos: kérjük a termékeket a mérő felület közepére helyezze, a mérleg pontatlan adatot mutathat, ha a terméket a mérőfelület szélre teszi.

3. A kikapcsoláshoz nyomja meg az “ON/ TARE/OFF” gombot 3 másodpercig, ha “0” jelenik meg a kijelzőn. A mérleg automatikusan kikapcsol, ha 60 másodpercig használaton kívül van.
4. Kapacitás: 5Kg ; beosztás: 1g
5. Túlerhelés: “EEEE” jel látható a kijelzőn, ha a mérleg túlerhelt.

♦ További méréndő anyagok hozzáadása

1. minden alkalommal, amikor az “ON/ TARE/OFF” gombot megnyomja, a kijelzőn a súly visszaugrik “0”-ra, függetlenül attól, hogy a mérő felületen már van méréndő anyag. Például:
Bekapcsolás → kijelző ‘0’ → Méréndő anyagot helyezzünk a mérlegre → akijelzőn megjelenik a súlya → Nyomja meg az “ON/ TARE/OFF” gombot → visszaáll “0”-ra → Helyezzen rá új méréndő anyagot → kijelzi a hozzáadott anyag súlyát → Nyomja meg az “ON/ TARE/OFF” gombot → visszaáll “0”-ra

Tisztítás és tárolás

1. Puha, enyhén nedves ruhával tisztítsa a mérleget és ha szükséges egy kevés mosószeret adjon hozzá. Soha ne használjon forró vizet vagy erős vegyszert a tisztításhoz.
2. Győződjön meg róla, hogy nincs semmi a mérő felületen, ha a mérleg használaton kívül van.
3. A mérleget ne tárolja az oldalára állítva.
4. Soha ne nyissa ki a mérleget és ne állítsa el a mechanizmusát és az áramkörét.
5. Távolítsa el az elemeket, ha hosszabb ideig nem használja a mérleget.

Ez a termék az alábbi irányelveknek felel meg:

RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863

Elektromágneses összeférhetőségre vonatkozó irányelv (EMC) – 2014/30/EU



Ez a szimbólum a termék csomagolásán és a használati útmutatón jelzi, hogy a készülék élettartama lejárta után a szelektív gyűjtőbe kerüljön elktölönítve a háztartási hulladékot. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságot.

VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.



Forgalmazó: Cool Collection, 1476 Budapest, Pf:176. Magyarország

Cégjegyzékszám: 01-09-276783

Származási ország: Kína